

## Cautions

1. Please keep the manual properly, if the manual are accidentally lost, manufacturing number on the fuselage will be used as the warranty basis.
2. The equipment should be installed indoors. If it needs to be installed outdoors, please add protective equipment to prevent any damage caused by sun and rain.
3. The equipment should be maintained by the distributor or installer once a year or more (such as replacing the hose, cleaning the tank, etc.) to maintain the regular operation and extend the service life of the equipment.
4. Hot spring areas, coastal areas, chemical factories, etc. as high PH contains in the air, resulting in abnormal or corroded equipment, not covered by the warranty.
5. Damage or abnormality of equipment caused by dust or insects from ants, cockroaches, rats or other animals, not covered by the warranty.
6. Do not splash water or wipe it with a damp towel on the main system and also related components to avoid damage to electronic components or electric shock.  
Please turn off the power switch and wipe with a dry towel before cleaning.
7. Keep the equipment dry and clean.  
The installer should carry out necessary protection according to the environment. For example, if it is installed on wooden floor, wooden kitchen utensils or there are items that are easily damaged by water leakage, measures should be taken to prevent leakage on water and electricity. It is recommended to install a leaking detector or other protective equipment. The installation area should have drainage facilities to avoid property damage caused by abnormal or old equipment or water leakage. Property damage outside the equipment is not covered by compensation.
8. Before installation, please confirm if the inlet water pressure is sufficient or even too high. If water hammer is exist, please install a pulsation damper and maintain it regularly operation of the pulsation damper, such as excessive water pressure or Water hammer causes equipment damage and is not covered by the warranty.
9. If the equipment is abnormal, please inform the distributor or installer to have further check. Unauthorized change for the equipment parts or setting value, resulting in abnormal equipment is not covered by the warranty.
10. The water pressure rate of the system is 10~40psi. If the inlet water pressure is too high, it will cause the pipe to leak or fall off easily.